

## INSTALLATION:

- TIGHTEN NUTS BY HAND WITH A NUT DRIVER AS SPECIFIED. DO NOT OVER-TIGHTEN SINCE STRIPPING WILL RESULT.
- TIGHTEN 3 TURNS AFTER CONTACT WITH FLAT WASHER.
- 2. 3. TIGHTEN 1-1/4 TURNS AFTER CONTACT WITH TANK, 10 IN.-LBS. MAX.

3	20	34700700		ASM BOLT KIT BOLTED SEALED MANWAY			
2	1	35900439		LID PE 20IN MANWAY			
1	1	33100136		GASKET PE 20IN SEALED MANWAY			
ITEM NO.	QTY.	PART NUMBER		DESCRIPTION			
DO NOT SCALE DRAWN BY			DRAWN BY	CHVDED	TITLE:		REVISION
Released IGG			IGG	INDUSTRIES, INC.	ASM MANWA	_	Α
© SNYDER INDUSTRIES, INC., 2018					SEALE	:D	SHEET 1 OF 1
ALL DIMENSIONS, DESIGNS, AND INFORMATION ON THIS PRINT MUST BE CONSIDERED PROPRIETARY 10 SNYDER INDUSTRIES, INC. AND MAY NOT BE USED, COPIED, OR DISTRIBUTED WITHOUT WRITTEN PERMISSION OF AN OFFICER (OR HIS AGENT) OF THE FIRM.				(402) 467-5221 www.snydernet.com	PART NO. <b>34700439</b>	ENG. ID. <b>D008976</b>	•

ALL DIMENSIONS ARE IN INCHES, NOMINAL, & SUBJECT TO CHANGE WITHOUT NOTICE. ALL DIMENSIONS ON ROTATIONAL MOLDED PARTS ARE SUBJECT TO A  $\pm$  3% TOLERANCE.