





IF INSTALLING VENT ON EXISTING TANK IN THE FIELD

1. ENSURE TANK HAS A 19" DIAMETER FLAT AREA FOR VENT.
2. TRIM A 16.25" HOLE ON A FLAT AREA ON THE TOP OF THE TANK WHERE VENT IS TO BE INSTALLED.
3. DRILL OUT EIGHT SCREW LOCATION ON VENT (NOT TANK) USING 1/8" BIT. START SCREWS INTO HOLES.
4. APPLY A BEAD OF SILICONE AROUND BOTTOM SIDE OF FLANGE THAT WILL SEAT AGAINST TANK.
5. PLACE VENT INTO PREVIOUSLY CUT HOLE ON TANK. FASTEN EIGHT SCREWS USING RIGHT ANGLE DRILL.



③ NOT SHOWN

3	1	99000288	BOX 26X26X20 S-4963
2	8	35200226	SCREW #10 X 1-1/2LG HWLSLM 18-8 SS
1	1	1035000N__01	ASM VENT 18IN MUSHROOM TRIM
ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
DO NOT SCALE		DRAWN BY	REVISION
Released		TS	B
© SNYDER INDUSTRIES, LLC, 2020		STI SNYDER INDUSTRIES	TITLE: VENT 18IN MUSHROOM
ALL DIMENSIONS, DESIGNS, AND INFORMATION ON THIS PRINT MUST BE CONSIDERED PROPRIETARY TO SNYDER INDUSTRIES, LLC. AND MAY NOT BE USED, COPIED, OR DISTRIBUTED WITHOUT WRITTEN PERMISSION OF AN OFFICER (OR HIS AGENT) OF THE FIRM.		(402) 467-5221 www.snydernet.com	REVISION SHEET 1 OF 1
		PART NO. 1035000N__03	ENG. ID. D003527

ALL DIMENSIONS ARE IN INCHES, NOMINAL, & SUBJECT TO CHANGE WITHOUT NOTICE.
ALL DIMENSIONS ON ROTATIONAL MOLDED PARTS ARE SUBJECT TO A ± 3% TOLERANCE.