




IF INSTALLING VENT ON EXISTING TANK IN THE FIELD

1. ENSURE TANK HAS A 19" DIAMETER FLAT AREA FOR VENT.
2. TRIM A 16.25" HOLE ON A FLAT AREA ON THE TOP OF THE TANK WHERE VENT IS TO BE INSTALLED.
3. DRILL OUT EIGHT SCREW LOCATION ON VENT (NOT TANK) USING 1/8" BIT. START SCREWS INTO HOLES.
4. APPLY A BEAD OF SILICONE AROUND BOTTOM SIDE OF FLANGE THAT WILL SEAT AGAINST TANK.
5. PLACE VENT INTO PREVIOUSLY CUT HOLE ON TANK. FASTEN EIGHT SCREWS USING RIGHT ANGLE DRILL.



UPSIDE DOWN VIEW

ALL DIMENSIONS ARE IN INCHES, NOMINAL, & SUBJECT TO CHANGE WITHOUT NOTICE.
ALL DIMENSIONS ON ROTATIONAL MOLDED PARTS ARE SUBJECT TO A $\pm 3\%$ TOLERANCE.

DO NOT SCALE		DRAWN BY	STI SNYDER INDUSTRIES, INC.	TITLE:	REPLACEMENT VENT 18IN MUSHROOM HD/BLK	REVISION
STATUS: Released		TS		ENG. ID.		
© SNYDER INDUSTRIES INC., 2015			(402) 467-5221 www.snydernet.com	PART NO.	103500N97803	SHEET
ALL DIMENSIONS, DESIGNS, AND INFORMATION ON THIS PRINT MUST BE CONSIDERED PROPRIETARY TO SNYDER INDUSTRIES, INC. AND MAY NOT BE USED, COPIED, OR DISTRIBUTED WITHOUT WRITTEN PERMISSION OF AN OFFICER (OR HIS AGENT) OF THE FIRM.				ENG. ID.		D003527